



439 PINK SPRAY PUTTY

Page 1/2
Revised: April 2008

DESCRIPTION	439 PINK SPRAY PUTTY is a premium high build spray putty for fast filling of minor indentations and scratches in automotive refinishing under Protec 330 Acrylic Lacquer topcoats.
PRODUCT #	<ul style="list-style-type: none">• 439 - 4115
FEATURES	439 PINK SPRAY PUTTY exhibits the following outstanding properties. <ul style="list-style-type: none">• High Solids and high build.• Fast dry.• Easy sanding.• Exceptional filling power.• Easy application.
SUITABLE SUBSTRATES	<ul style="list-style-type: none">• 439 PINK SPRAY PUTTY has been designed for application over surfaces previously primed with 432 ACRYLIC PRIMER SURFACER.• Not recommended as a filler for cracked painted surfaces.
SURFACE PREPARATION	<ul style="list-style-type: none">• Surfaces to be painted must be sound, previously primed with 432 ACRYLIC PRIMER SURFACER, sanded and washed clean with R123 H.D. WAX AND GREASE REMOVER.
DRYING	<ul style="list-style-type: none">• Under normal ambient conditions, 439 PINK SPRAY PUTTY can be sanded after drying for one hour.• For heavy applications of putty, the drying time should be increased accordingly.
THINNING	<ul style="list-style-type: none">• Supplied ready for use by low pressure spray gun with pressurised cup. Can be sparingly thinned with R100 LACQUER THINNER OR R103 ALL PURPOSE THINNER if desired.
APPLICATION	<ul style="list-style-type: none">• Apply using a low pressure spray putty gun with attached pressurised cup. Air pressure at the gun should be 170-200 kPa. Do not exceed 200 kPa. Apply 2 or 3 coats to the repair area allowing 15 minutes flash off between coats. Allow to dry, sand smooth and dust down. Immediately apply 432 ACRYLIC PRIMER SURFACER over the spray putty as a foundation for the acrylic top coat.
SANDING	<ul style="list-style-type: none">• Sand with 360 paper or finer.
RECOATING	<ul style="list-style-type: none">• 432 ACRYLIC PRIMER SURFACER must be applied over 439 Spray Putty before applying 330 ACRYLIC LACQUER topcoat. Do NOT apply 330 ACRYLIC LACQUER directly onto 439 SPRAY PUTTY.
PACK SIZES	<ul style="list-style-type: none">• 1 Litre• 4 Litres• 20 Litres



439 PINK SPRAY PUTTY

Page 2/2
Revised: April 2008

HEALTH AND SAFETY

Contains highly flammable volatile solvents. Keep away from all sources of heat and open flames. Do not smoke whilst handling. Wear suitable protective clothing to avoid contact with skin and eyes and avoid breathing vapour. Do not spray in confined or poorly ventilated areas without the use of approved air supplied breathing apparatus.

FIRST AID

Eyes	If splashed in eyes, irrigate with copious amounts of clean water for 15 minutes. Seek medical aid if irritation persists.
Skin	If splashed on skin, wash affected area thoroughly with soap and water. If irritation persists seek medical aid. Remove all contaminated clothing and launder before re-use.
Inhalation	If affected by exposure to vapours, remove from area, keep at rest and seek medical aid if symptoms persist.
Ingestion	If swallowed, give glass of water to drink and seek medical assistance. DO NOT induce vomiting.

Consult separate Material Safety Data Sheet for more detailed Health and Safety information.