

## PARAGLAZE MATT CLEARCOAT SYSTEM

### PRODUCT DESCRIPTION

The Paraglaze Matt Clearcoat System is designed for use over Paraglaze Basecoat.

It uses Paraglaze Ultra Finish Clearcoat and Paraglaze Matting Base to produce a range of low gloss levels for custom finishes or repairs over low gloss OEM finishes. To allow for normal variations in gloss due to colour, position of repair on vehicle etc., the mix ratios can be adjusted to match the vehicle to be repaired.

### SUBSTRATES & PREPARATION



Paraglaze Matt Clearcoats must be applied on top of:

- Clean and dust-free Paraglaze Basecoat. The use of a clean tack rag is recommended to remove dust from the basecoat film before topcoating.
- Sound OEM finishes that have been degreased and sanded.
- Sound, fully cured 2 pack refinish finishes that have been degreased and sanded.
- Substrates other than those stated above should be tested before use, to ensure that the performance of this product is suitable for its intended use.

Minimise direct contact of masking tape onto the original low gloss finish.

- When necessary to do so, the tape must be removed before baking to avoid marking of the original finish, which may not recover.

Avoid dirt inclusion at all stages: rectification of dirt inclusion in low gloss finishes is not possible after the final coat of clearcoat.

### PRODUCTS

Paraglaze Ultra Finish Clearcoat	PC-5950
Matting Base	PT-G132
Paraglaze Hardeners	PH-4200 or PH-4300
Paraglaze Reducers	PS-6100 or PS-6200 or PS-6300

## GLOSS ADJUSTMENT GUIDE

To allow for normal variations in the gloss level, depending on the colour, model, position of repair on vehicle etc., it is possible to mix PC-5950 and PT-G132 in any ratio to match the required gloss for a particular repair.


The percentage ratios quoted below give the best starting point for the five gloss level ranges:

Gloss Code	MC01	MC02	MC03	MC04	MC05
Gloss Effect	Matt		Low Gloss		Semi Gloss
Gloss Range	0 - 10%	10.1 - 20%	20.1 - 30%	30.1 - 45%	45.1 - 60%
Ingredient	Percentage (%) By Weight				
PC-5950	30	35	40	45	50
PT-G132	70	65	60	55	50

Activate and reduce the resulting mix as below.

Note: Test panels MUST be sprayed out using the intended hardener/reducer ratio and spraygun combination to check for colour and gloss level against the vehicle to be repaired.

## MIXING RATIO BY VOLUME




### PRODUCT

Paraglaze Matt Clearcoat  
PH-4200 or PH-4300  
PS-6100, PS-6200 or PS-6300

### PARTS


2  
1  
10%

## POTLIFE



1 hour at 25°C

## SPRAY VISCOSITY



17 - 19 seconds (DIN 4) at 25°C

## SPRAYGUN



### SETUP

1.3 mm - 1.4 mm

### SPRAY PRESSURE

- HVLP / RP 2 bar
- CONVENTIONAL 2 - 3 bar (200 - 300 kPa, 29 - 44 psi)

## APPLICATION & FLASH OFF




### 1st Coat

Flash Off

### Apply an even, medium coat

Allow to flash off fully until evenly matt before applying the second coat.



### 2nd Coat

### Apply an even, wet coat

Note: Apply the 1st coat to all but the final 10cm of the fade out panel and allow to flash off. Then apply the 2nd to the whole repair area.

## BAKE TIME & TEMPERATURE



### 40 minutes at 65°C

Note: Drying times will need to be extended under cooler conditions. Seek further advice before spraying. Temperature shown is metal temperature.

## TOTAL DRY FILM BUILD

50 - 60 µm

## OVERCOAT / RECOAT



### PREPARATION:

P500 dry abrasive or P800 wet abrasive, after bake.

### TIME:

Minimum of 8 hours after bake.

## EQUIPMENT CLEANING

After use, clean all equipment thoroughly with cleaning solvent or thinner.

## PERFORMANCE & LIMITATIONS

The gloss levels achieved with this system will vary depending on film build and application:

- Low film build and dry application will give a lower gloss.
- High film build and wet application will give a higher gloss.

Removal of minor dirt inclusions in the final finish:

- Fully dry the repair, denib after cooling and apply one further coat of the clearcoat mix.
- Take care to avoid too high a film build as the final colour could be affected. If this occurs, the repair will require sanding and recoating with basecoat and clearcoat.

Dirt removal from the final low gloss finish is not possible.

## GENERAL CARE & MAINTENANCE OF LOW GLOSS FINISHES

*The following guidance is aimed at the car owner and applies to both the OEM and repair finish.*

*Particular care is required to maintain the even low gloss effect over time.*

General handling and day to day use (opening the door/bonnet/boot, shoe scuffing on entry or exit to the vehicle etc.): take care with these operations as low gloss finishes can be relatively easily marked and the low gloss effect could be altered.

Fuel spillage: take care to avoid and remove spillage as soon as possible using the below guidelines, to prevent permanent damage or altering of the low gloss finish.

Polishing: • Avoid the use of abrasives, polishes and wax polishes

- Do not polish the vehicle as this will lead to a higher, uneven gloss

Cleaning: • The preferred method is by hand with a soft sponge, neutral soap and plenty of water.

- Avoid the use of automated car washing machines and paint cleaners as cleaning with unsuitable materials could alter the low gloss effect (generally increasing the gloss).
- Too frequent car washing could, over a period of time, lead to higher and inconsistent gloss levels across the vehicle.
- Avoid washing under direct sunlight.
- Insect and bird residues should be removed immediately: soak in water and/or remove with high pressure cleaning equipment. In the case of strongly adhered residues, a spray on insect remover should be used prior to washing.
- When using any type of cleaning fluid with a soft sponge or cloth, it is essential not to apply pressure or rub the low gloss finish: use a gentle wipe/spray on and wipe off technique.

## HEALTH AND SAFETY

**Please refer to Material Safety Data Sheets for full Health and Safety details, as well as product can labels.**

Paraglaze Hardeners and activated products contain isocyanate and therefore particular safety precautions must be taken.

Goggles must be worn when mixing and using to prevent accidental splashing into the eye. If contact occurs with eyes give prolonged irrigation with water and get medical attention immediately.

Good ventilation and extraction must be provided in the working environment.

Wear suitable protective equipment to prevent skin contact with this material.

When spraying this product the operator (and persons in vicinity) must wear suitable air-fed breathing apparatus. Do not smoke whilst using this material.

This product is for professional use only.  
The information given in this sheet is for guidance only. Any person using the product without first making further inquiries as to the suitability of the product for the intended purpose does so at his or her own risk and we can accept no liability for the performance of the product or for any loss or damage (other than death or personal injury resulting from our negligence) arising out of such use. The information contained in this sheet is liable to modification from time to time in the light of experience and our policy of continuous product development.  
Drying times quoted are average times at 25°C/77°F. Film thickness, humidity and shop temperature can all affect drying times.

Before using, refer to the Material Safety Data Sheet obtainable from Protec Pty Ltd.

Follow all directions and warnings fully and carefully. Otherwise do not use this product.

**Protec Pty Ltd. 97–105 Bedford Street, Gillman, S.A. 5013 Australia**

**EMERGENCY RESPONSE NUMBER: Australia: 1800 883 254**

**Protec Pty Ltd. 5 Monahan Rd, Mt Wellington, Auckland, New Zealand**

**EMERGENCY RESPONSE NUMBER: New Zealand: 0800 000 096**